

# DISABLED PERSONS TOILET ALARM KIT

EN

PLEASE READ INSTRUCTION BEFORE COMMENCING INSTALLATION AND RETAIN FOR FUTURE REFERENCES.

! Electrical products can cause death or injury, or damage to property. If in any doubt about the installation or use of this product, consult a competent electrician

**Note:**

Product technical information and specification may change over time without prior notification. For the latest technical information please visit our web site [www.ledgrouprobust.com](http://www.ledgrouprobust.com) or [robustdirect.com](http://robustdirect.com)

5°C < Ta < +40°C, 220-240V ~ 50/60Hz, Class I, IP20  
Suitable for mounting on a normally flammable surface.

**Installation**

1. Ensure mains supply is switched off before commencing work
2. Before drilling ensure that the hole does not impinge on joists, pipe work, cables or other building services
3. Reset unit to be fitted in the bathroom
5. the Over Door Indicator and Sounder should be fitted outside the bathroom in a position where viewing of it will not become obstructed
6. Insert supplied 12V battery to main control panel
7. Connect main supply to Main Control Panel ( Brown-Live, Blue-Neutral, Green /Yellow - Earth). Then link output terminals to corresponding terminals in the other devices.

**Main Control Panel:** Will be located in the most appropriate place that a responsible person/staff member can see the panel. the panel requires a 25mm double back box.  
**Reset Panel:** Shall be located in the cubicle. The panel shall be mounted so that it can be operated from the WC. Mounting height should be between 700mm and 1200mm from finished floor level. The rest panel requires a 25mm surface or flush single back box.  
**Alarm Pull Cord:** Shall be located in the ceiling in the position so that it can be operated from the WC. Two handles are provided with the unit. it is recommended that the upper handle shall be adjusted so that it situated between 800mm and 1000mm from finish floor level. the lower handle shall be located at 100mm from finished floor level.  
**Over-Door Indicator and Sounder:** shall be located in a positioned outside the WC, preferably over the door of the toilet so it can be seen by responsible person.

**Information for the Product user:**

1. Please note the requirement to dispose of Waste Electrical & Electronic Equipment separately from household waste (WEEE marked with crossed out wheelie bin symbol).
2. Please consider your role in contributing to re-use and recycling by returning this product at end of life to a collection centre for waste electrical equipment or a Civic Amenity site, or to a retail outlet from which you are purchasing a replacement.
3. This equipment may contain substances that are hazardous to health and the environment if disposed of carelessly. It is important that it is separated from normal household waste and recycled in the WEEE chain
4. The "crossed out wheelie bin symbol" on a product indicates this equipment must not be disposed of in normal household waste, but should be disposed of according to local WEEE regulations

The Installation must be carried out by a qualified electrician

